



PLANTA DE UBICACIÓN

ESC. 1/50

CUADRO DE PROPIEDADES ZAPATAS

Nombre	Sección (cm)	Pilar								Fundación				
		X (cm)	Y (cm)	Carga Máx. (tf)	Carga Mín. (tf)	Mx (kgf.m)	My (kgf.m)	Fx (tf)	Fy (tf)	Lado B (cm)	Lado H (cm)	h0 / ha (cm)	h1 / hb (cm)	df (cm)
P1	25x25	72.50	464.50	3.4	3.2	0	0	0.4	0.8	70	70	25	25	150
P2	25x25	411.00	464.50	4.9	4.6	800	200	0.4	1.3	100	100	25	25	150
P3	25x25	844.50	464.50	4.7	4.4	800	400	0.8	1.5	100	100	25	25	150
P4	25x25	1034.50	464.50	3.1	2.8	700	100	0.1	1.4	105	105	20	30	150
P5	25x25	72.50	12.50	3.4	3.2	200	200	0.5	0.8	70	70	25	25	150
P6	25x25	411.00	12.50	5.5	5.3	500	200	0.4	1.3	95	95	25	25	150
P7	25x25	844.50	12.50	5.2	5.0	600	400	0.8	1.5	95	95	25	25	150
P8	25x25	1034.50	12.50	3.0	2.7	700	100	0.1	1.4	105	105	20	30	150